



codice-code code-Best.Nr.	a1 0/-0.5	a2	c ~	b1 ±0.01	b2 ±0.01	e	f	h	d5-d6 H7	l1	.GG kg	.AL kg
021.010	320	320	40	160				40	20	100	30	10
021.030	400	400	50	200		55	25	40	20	150	50	18
021.050	500	500	60	250		75	25	40	20	200	75	25
021.070	630	630	70	315		100	25	40	20	200	120	40
021.100	800	800	100	400		135	25	50	20	300	190	75
021.020	320	400	40	160	200			40	20	100	35	15
021.040	400	500	50	200	250			40	20	150	60	20
021.060	500	630	60	250	315			40	20	200	90	30
021.080	630	800	70	315	400			40	20	200	145	50
021.110	800	1000	100	400	500			50	20	300	240	85

indicare con la richiesta le caratteristiche di interfacciamento alla macchina - on the request put the interface features to the machine
 il faut indiquer dans votre demande les caractéristiques d'interface à la machine - bei Anfrage bitte Info über die Palettschnittstelle